

DELL 1320/ XEROX C1110/XEROX6130 chips instruction manual:



Use a screw to push the chip housing out of the cartridge



When housing disassembled, you can see chip within its housing.



Use a screw to push down the chip.



Chip and housing. Use the opposite steps to assemble if necessary.

For more information, contact us as below:

E-mail: info@tonerchips.com